

Installation tips

flexim® 2013



→ Remove the lightweight, ready-to-use FLEXIM strips from the packaging. Use the cover of the FLEXIM box to carry the strips onto the roof.



→ Tip: Make a small table to sit FLEXIM strips on to help when working.



→ Mark the position of the butt-joint with a piece of chalk.



→ Apply FLEXIM along tile or slate, using the gloves provided.



→ Important: Make sure the joints are completely filled with FLEXIM.



→ Press ridge-cap, with clean hands, firmly down into the centre of the bar, ensuring that FLEXIM is both inside and outside of the ridge-cap. Keep the joints as tight as possible.



→ Trowel off all excess FLEXIM with your putty knife. You can reuse the excess FLEXIM. Smooth out the FLEXIM until an even finish is achieved.



→ A small amount overflowing is ok because you can clean the joints with a finger/spatula.



→ Use a spatula, pointing trowel or your finger to tidy up joints. Immediately after use, clean the hands, tools and any contamination on the tiles with a dry cloth.

Tip step 5

Save money, you don't waste material on butt joints, use broken tiles!



You can use broken tiles (pieces of tiles) to fill up the space under the ridge-cap.



→ Make sure there is enough FLEXIM between the broken tiles and the ridge caps.



→ Press ridge-cap, with clean hands, firmly down into the centre of the bar, ensuring that FLEXIM is both inside and outside of the ridge-cap.

Any questions or need help? Call us on: 01943 607 538

www.fleximroofputty.com